

STRIBERIG

Sägerahmen

Check grid rod, bushings
and springs are properly fasted
(#30, 31, 32)

